


# Replacing LCM4 Controller Battery



1. Remove 2 screws from 2nd cover plate.
2. Gently pull card out.
3. 5-yr Lithium Battery Plugs into this card.
4. Remove existing battery from velcro strip and unplug.
5. Plug in new battery and press new battery against velcro strip.
6. Slide card in grooves into place. Press gently to engage socket.
7. Replace to plate and 2 screws.

**TADIRAN**  
TL-5242/W  
6V HIGH ENERGY  
LITHIUM BATTERY  
MADE IN ISRAEL

**WARNING: FIRE, EXPLOSION  
AND SEVERE BURN HAZARD.**  
**DO NOT RECHARGE, DISASSEMBLE,  
HEAT ABOVE 100°C, INCINERATE  
OR EXPOSE CONTENTS TO WATER.**

20-70

OPTO-22  
LCM4 SERIAL

LCM4 SERIAL

— 10 —